

Installation Instructions
52" -60" -72" Discharge Baffle

1. Remove the stock discharge baffle (2 bolts)
2. Remove the nut on the underside of the deck to the rear of the deck
3. Install the new Extreme Baffle and rest it up against the blade spindle housing
4. Put the rear nut on the finger tight and put the bolt and nut on by the discharge opening
5. Put the other nut back on the exposed bolt
6. Tighten all bolts and nuts to 30ft. Lbs.

*To see a picture on the website, go to redmagicperformance.com

**For parts and accessories, contact Brady Peters at Red Magic
Performance Products (712) 541-7640**



Red Magic Performance Products LLC