

Installation Instructions

52", 60", 72" Max Vac Baffle for Exmark Series 4 & 6 decks

1. Align baffles so that the bottom edge is level with the front edge of the mower deck
2. Make sure that the two baffles come together evenly in the center of the deck
3. Measure holes in baffles and drill from the outside of the deck
4. Install provided 3/8x1-1/4 carriage bolts. Place carriage head side on the inside of the deck through slotted hole in baffle. Tighten to 50ft. Lbs
5. Double check blade clearance by rotating blades a full 360°
6. To maximize bagging performance install our extreme discharge baffle as shown in the picture below.



**For parts and accessories, contact Brady Peters at Red Magic
Performance Products (712) 541-7640**



Red Magic Performance Products LLC