

Toro Timemaster 30" Installation Instructions

1. Take off the front axle cover



2. Remove top nuts and bolts with 3/16" allen wrench and 1/2" box wrench or socket. Retain nuts to reuse in step 3
3. Install the Mounting Bracket to the front of the mower deck using the supplied longer bolts and nuts from step 2



4. Install L & R arms to the Mounting Bracket using the supplied 5/16 locking pin
5. Install the tine bar with tines and using the supplied 5/16x1-3/4 bolts
6. Install caster wheels to arms
7. Adjustments are made via 1/8" allen wrench on locking collars on the wheel shaft and/or the three holes in the Mounting Bracket

Exmark Commercial 30 Installation Instructions

1. Replace 4 bolts on front of deck with supplied longer bolts
2. Install both L & R Arms and put pins in
3. Adjustments are made via 1/8" allen wrench on locking collars on the wheel shaft and/or the three holes in the Mounting Bracket

For parts and accessories, contact Brady Peters at Red Magic Performance Products (712) 541-7640



Red Magic Performance Products LLC