

TORO TURFMASTER

INSTALLATION INSTRUCTIONS

1. Hold and center the mounting bracket to the front of the deck as shown.
2. Drill 2 5/16" holes and use the bolts and nuts that are provided. (2 - 5/16" bolts and 2 - 5/16" nuts).
3. Install tine bar with tines and with the pins that are supplied.
4. Install thatcher wheels. Adjustments are made via locking collars on wheel shaft and/or the 3 holes in the mounting bracket.

For parts and accessories, contact Brady Peters at Red Magic Performance Products (712) 541-7640



Red Magic Performance Products LLC