

10. Install Universal armbar/stabilizer bar to keep bagger frame vertical. Insert 2 – 3/8x1 carriage bolts with flanged lock nuts in slotted section of each section so that the 11/16” holes are on each end





Once desired length is determined, a 3rd carriage bolt can be installed to lock adjustable stabilizer bars length. Drill a 3/8" hole through one of the square holes on either end.

